

Installation, Operation & Maintenance Manual
GPS-iRIB-18 and GPS-iRIB-36



Thank you for purchasing a GPS-iRIB™ from Global Plasma Solutions. The GPS-iRIB is a highly versatile device designed to be installed on the coiling coil of ductless systems or PTACs. The units can be installed on systems where there may not be enough room between the filter and the coil for traditional GPS products. The unit comes with adhesive-backed hook and loop tape for ease of installation.

DUCTLESS MINI-SPLIT AND PTAC MOUNTING AND WIRING INSTRUCTION

1. Turn off the power to the air handling unit (AHU).
2. Remove the filter screens and the cover to expose the coil surface and the power box.
3. Determine where you want to mount the ionization strip on the AHU.
4. Peel off the loop section from the GPS-iRIB and then peel off the paper layer to expose the adhesive.
5. Carefully attached the adhesive backed loop on the AHU at the desired location. Some mini split systems come with a plastic strip along the top of the coil. If so, mount the GPS-iRIB to the plastic strip. Otherwise mount the GPS-iRIB on the finned surface. See [FIGURE 1](#).



CAUTION – keep the emitter tips away from loose wires or any grounded parts.

6. Each AHU brand will have different space constraints for the power supply. Find an appropriate space to mount the power supply using the included hook and loop tape. Press the power supply firmly to the mounting location. See [FIGURE 1](#).
7. Run the wires to the electrical compartment. Connect the black wire to 100-240VAC and the white wire to neutral. For 208-240VAC installations, connect the white wire to the other hot leg, depending on the power supplied.
8. Trim the wires to length and connect to the appropriate power terminals, normally L1 and L2. Secure wires properly with wire ties or other NEC approved methods.

Figure 1



OPERATION

1. Turn on power to the AHU.
2. The ion device will be powered when power is applied to the AHU. Note: the ion device is designed to remain energized 24/7 and does not have to cycle with the fan.
3. Once unit is energized, the integral LED on the power pack will illuminate, indicating the unit is active.

BAS ALARM OPERATION

1. The purple wires connect to the integral alarm relay. When the unit is powered and there are no faults, the alarm contacts will be closed. When there is a fault, the contact will open.

MAINTENANCE

1. Remove power from the AHU and remove the required parts to access the iRIB. Confirm the iRIB power supply LED is not illuminated. It is good practice to ensure all voltage is removed from the iRIB. Take a screwdriver with insulated handle and touch a carbon fiber brush brass connector on one side to another on the opposite side. This will discharge any remaining voltage that could cause a potential shock hazard during maintenance.
2. Use a wet wipe or damp cloth to clean the iRIB. A soft bristle brush, like a toothbrush, can also be used to clean debris from ion emitters. Do not expose the iRIB to corrosive cleaners.



Engineering Air for a Cleaner World™

3101 Yorkmont Road • Suite 400
Charlotte, NC 28208
980-279-5622

GlobalPlasmaSolutions.com

GPS, GPS-iRIB and its logos are trademarks of Global Plasma Solutions, Inc.
©2020 Global Plasma Solutions, Inc.



033020-GPSIRIB-IOM

Engineering Air for a Cleaner World™